

**Case 850D, 855D Crawler Dozer Operators Owner Instruction Manual** COMPONENTS: INTRO

To the Proprietor After Shipment Examine Right, Left, Front, and also Back of Maker Recognition of



Maker Parts



CONTROLS AND INSTUMENTS Instrument Panel Foot Pedals Transmission Controls Neutral Lock and Starter Button Master Disconnect Switch Parking Brake Loader Lift Arm and Bucket Control 4-In-1 Bucket and Ripper Controls Dozer Controls Winch Control Backhoe Controls with Foot Swing Backhoe Controls with Hand Swing Extendahoe Controls with Foot Swing Extendahoe Controls with Hand Swing Backhoe Power Control Suspension Seat Seat Belts Cab Controls OPERATING INSTRUCTIONS Engine Operation - Walk-Around Inspection - Starting the Engine - Operating Turbocharged Engine - Engine Speed - Parking the Machine and Stopping the the Engine - Methods to Help Start the Engine During Cold Weather Crawler Operation - Transmission Controls - Steering - Stopping the Crawler - Operating On Hill - Procedure to Transport the Machine - Moving a Disabled Machine Operating in Cold Temperatures Operating in Hot Temperatures Loader Operating Tips Dozer Operating Tips Winch Operating Tips Ripper Operating Tips Backhoe Operating Tips Backhoe Removal Backhoe Installation