

[New Holland FX30, FX40, FX50, FX60 Forage Harvester Factory Service Repair Manual](#)



Description Page
Op. 35.000 Circuit diagrams
Work Hydraulics
Attachment height control
Op. 35.300 Hydraulic oil reservoir
Low pressure filter
Breather
High pressure filter
Non--return valve

Description Page	Op. 35.000 Circuit diagrams	2
Work Hydraulics -- Attachment height control	Op. 35.300 Hydraulic oil reservoir	4
Low pressure filter	Breather	5
5 High pressure filter	5 Non--return valve	5
5 Function		
5 Op. 35.304 Work hydraulics pump	6 Specifications	6
6 High pressure relief valve	Op. 35.410 Attachment height control valve (EMR)	8
Neutral position	10	
Attachment lifting position	10	Attachment lowering position
11	Pressure relief valve h	11
Emergency hand buttons	11	
Specifications		11
Attachment compensation valve	12	Specifications
12 Transport mode	14	
Compensation mode	14	
Stubble height mode	14	
Pressure sensor		
15 Specifications	15 Hydropneumatic accumulators	
16	Filling	17
Attachment lift cylinders	18	